


MODEL






2SA699 2SC1226







Semiconductor name	Substitutions				
2SA564	2SA733				
2SA699	2SB595, 2SB596				
2SA721	2SA640, 2SA620WB				
25822	_				
2SC828	2SC536, 2SC945				
2SC1226	2SC1013				
2SC1327	2SC1000				
AN360	-				
NE545B	-				
TA7060P	_				









STEREO CASSETTE DECK



(KX-1003) **KX-1030** (






Front Loading Stereo Cassette Deck with Dolby System Type Track System 4-Track, 2-Channel Stereo/Mono Recording/Playback AC Bias System (Bias Frequency: 85 kHz) Recording System Erasing System AC System 4.76 cm/sec (1-7/8 ips) Tape Speeds Three Ferrite Heads Type
Recording and Playback Combination Head x 1 Heads Erasing Head x 1
Electronically-Controlled DC Motor Motor Fast Winding Time Approx. 80 seconds with C-60 tape Normal Tape: 25 Hz to 17,000 Hz (35 Hz to 15,000 Hz±3 dB) Frequency Response CrO₂ Tage: 25 Hz to 20,000 Hz (35 Hz to 18,000 Hz+3 dB) Ferri-CrO₂ Tape: 25 Hz to 19,000 Hz (35 Hz to 17,000 Hz±3 dB) Signal to Noise Ratio Dolby ON (Over 5 kHz): 65 dB (Normal Tage), 67 dB (CrO₂) Dolby OFF: 55 dB (Normal Tape), 57 dB (CrO₂) Harmonic Distortion Less than 1.3% (at 1 kHz, OVU with Normal Tape) 0.06% (WRMS) Line x 2: 77.5 mV/56k ohms Input Sensitivity/Impedance 0.1 mV/1.0k ohms: Europe and Scandinavia model
DIN x 1: 10.9 mV/1.5k ohms: Other Countries model Microphones x 2: 0.19 mV/10k ohms Line x 2: 775 mV (0VU)/2.0k ohms Output Level/Load Impedance DIN x 1: 775 mV (0VU)/2.0k ohms Headphones/1: 48.9 mV/8 ohms to 16 ohms Three Ferrite Heads Type
Dolby Noise Reduction System with Indicator **Build in Features** Three Position Bias Selector (Normal-Chrome-Reserve) Three Position Equalization Selector (Normal-Chrome-Reserve) Fine Rias Adjustment Controls with Oscillator Full Auto Shut-Off Mechanism in all Modes Mic/Line Mixing Memory Rewind
LED Peak and Recording Indicator Three Digit Tape Counter Two Large Size Illuminated VU Meters Two Microphone Jacks, Headphone Jack DIN Rec/P B. Connector AC 120V, 60 Hz: USA and Canada I Power Requirements AC 220V 50 Hz: Australia Model AC 240V, 50 Hz: U.K. Model AC 120V/220V (Switchable), 50/60 Hz; Other Countries 13.0 watts W: 430 mm/16-15/16* Dimensions H: 167 mm/6-9/16" D: 332 mm/13-1/16" 7.5 kg, 16.5 lbs Weight Supplied Accessories Stereo Connection Cord x 2 Head Cleaning Kit x 1 Normal: TDK SD C-90 Reference Tape* Chrome: TDK SA C.60 Reserve: SONY DUAD C-60

TRIO follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.


NOTE: *Dolby is trademark of Dolby Laboratories, Inc.






NOTE: We reserve the right to make modifications in this model in accordance with technical developments.





ifications in this model in accordance with technical developments.

NV-INON VV-INON




ical developments.



Fig. No.	Parts No.	Description	Remarks		
106	D16-0207-08	Square belt		8B	
107	B09-0008-18	Reel cap		8A	
108	N19-0249-08	Polyethylene slider washer		8A	
		ϕ 1.6 × ϕ 6 × 0.25			
109	D14-0205-08	Idler ass'y	☆	88	
110	D14-0056-08	Idler "B" ass'y (REW idler)		88	
	-				
111	G01-0303-08	Idler "B" lever spring		88	
112	D19-0203-08	Pause slide holding plate		88	
113	D10-0479-08	Lever (2) ass'y for removing	☆	88	
		pause lock			
114	G01-0300-08	Pause lock plate spring		8B	
115	D12-0205-08	Pause lock plate	☆	8B	
116	D10-0476-08	Plate ass'y for unattended		8B	
		recording operation			
117	D10-0496-08	Tension arm ass'y "B"	☆	88	
118	G09-0203-08	Drive roller spring		88	
119	G01-0307-08	REW lever spring "B"		88	
120	G01-0302-08	FR lever spring "D"		8В	
121	D10-0201-08	REW lever "B"		88	
122	D10-0480-08	Muting lever ass'y	☆	8B	
123	D10-0483-08	FF lever	☆	8B	
124	A10-1015-08	Mechanism chassis ass'y	☆	8A	
125	G01-0639-08	Eject safty claw	☆	7A	
126	D21-0625-08	Cassette helf holding lever	☆	8A	
		shaft			
127	J21-2239-08	Mechanism holder "L" ass'y	☆	8A	
128	G09-0211-08	Cassette lock plate spring	☆	8A	
129	D12-0206-08	Cassette lock plate	☆	8A	
130	N09-0582-08	Screw with steps M3 × 5	☆	8A	
131	D19-0204-08	REC safety claw	☆	8A	
132	G09-0210-08	REC safety claw spring	☆	8A	
133	D10-0485-08	Cassette half holding lever	☆	8A	
134	G09-0209-08	Cassette half spring	☆	8A	
135	J31-0412-08	Faucet for mounting frame	☆	8A	
136	J31-0301-08	Felt faucet ass'y	☆	8A	
137	N09-0808-08	Flat head screw M1.6 × 4	☆	8A	
138	A13-0506-08	Angle for mounting mechanism	☆	8A	
139	D10-0482-08	Arm ass'y for preventing eject	☆	8A	
		operation		8A	
140	D10-0198-08	Brake lever		84	
4.4.4	002 0011 00	Broke lover enring		8A	
141	G03-0011-08	Brake lever spring	☆	8A	
142	D03-0007-18	Reel base ass'y	쑈	8A	
143	G01-0635-18 N19-0515-08	Back tension spring Washerφ6.2 × φ9.5 × 0.15	쑈	8A	
144 145	B11-0303-08	Prism plate	☆	9A	
145	G09-0208-18	Erase head plate spring	<u>"</u>	8,9A	
147	J21-2237-18	Erase head plate ass'y		9A	
148	T32-0004-08	Erase head	"	9A	
149	T34-0005-05	REC/PLAY head	☆	9A	
150	A11-0316-08	Head base ass'y	, .	8A	
150	A11-0310-00		1	-, ,	
151	G01-0629-08	Adjusting head spring	☆	8A	
152	G01-0630-08	Fixing head spring	☆	9A	
153	G01-0305-18	Pinch roller spring	•	9A	
154	D10-0467-18	Pinch roller arm ass'y	☆	9A	
155	G01-0634-08	Head base shaft spring		9A	
156	D39-0043-08	Head base shaft		9A	
157	G10-0631-08	Head base spring	☆	9A	
158	N09-0205-08	Screw with toothed washer M2 × 5		9A	
1					

Fig. No.	Parts No.	Description	Rem	Remarks		
159	N19-1020-46	Toothed washer		9A		
160	G02-0065-08	Head base holding spring		9A		
161	N09-0583-08	Hexagonal screw M2.6	☆	9A		
162	F01-0608-08	Head protector	☆	9A		
163	A29-0301-08	Cassette plate	☆	9A		
164	G09-0207-08	REC switch operation wire	☆	9A		
165	G01-0672-08	Brake operation lever spring (1)	☆	9A		
166	K29-0629-08	Pushbutton block ass'y	☆	9A		
167	D21-0623-08	Pushbutton shaft	☆	9A		
168	D10-0474-08	Pushbutton operation plate ass'y	☆	9A		
169	G01-0645-08	Pushbutton operation plate spring	☆	9A		
170	D10-0473-08	STOP pushbutton lever ass'y	ជ	9B		
171	G09-0206-08	STOP pushbutton spring	☆	98		
172	G09-0205-08	Pushbutton spring	☆	9A		
173	D10-0470-08	Pushbutton lever "A"	☆	9A		
174	D10-0471-08	Pushbutton lever "B"	☆	9A		
175	D10-0472-08	REC pushbutton lever	☆	94		
176	K29-0630-08	Operational pushbutton	☆	94		
177	D10-0475-08	Eject lever holder ass'y	☆	98		
178	D10-0481-18	Housing arm ass'y "L"	☆	94		
179	D10-0497-18	Housing arm ass'y "'R"	☆	98		
180	D10-0486-08	Housing arm interlock plate	₩	98		
181	J21-2238-08	Mechanism holder "R" ass'y	☆	88		
182	S59-1043-08	Reed switch		88		
183	D14-0206-08	Counter idler	☆	98		
184	D16-0208-08	Counter belt	☆	98		
185	B35-0203-08	Tape counter	☆	98		
186	G01-0636-08	Muting lever spring	☆	98		
187	X25-1330-00	MUTING SWITCH PC board ass'y	☆	9 E		
188	A15-0303-08	Frame for switch		96		
189	X25-1320-00	REC SWITCH PC board ass'y	☆	96		
190	J21-2262-08	Wire holder	☆	9E		
191	G01-0637-08	Housing arm spring	☆	9E		
192	F14-0106-08	Lamp tube	Ι.	88		
193	B30-0507-08	Pilot lamp 12V 60 mA	☆	8E		
194	G02-0311-08	Head base holding screw "B"		9,4		
195	N09-0813-08	Screw with toothed washer	1	9/		

Fig. No.	Parts No.
M2 × 8	N30-2008-46
M3 × 8	N30-3008-46
M3 × 4 (Bi-Tap)	N89-3004-46
M3 × 6 (Bi-Tap)	N89-3006-46
M2.6 × 4 (SEMUS)	N09-0199-08
M2.6 × 6 (SEMUS)	N09-0202-08
M2.6 × 7 (SEMUS)	N09-0200-08
M2.6 × 8 (SEMUS)	N09-0203-08
M2.6 × 15 (SEMUS)	N09-0201-08
M2 × 3 (F)	N32-2003-46
M3 × 5 (B)	N35-3005-46
M3 × 14 (B)	N35-3014-46
M2.6	N10-2026-46
мз	N10-2030-46
φ1.5 (ER)	N24-3015-60
φ2 (ER)	N24-3020-60
φ2.5 (ER)	N24-3025-60
φ3 (ER)	N24-3030-60
φ4 (ER)	N24-3040-60



V INAA

• : Refer to Destinations' Parts List

☆ : New parts

Fig. No.	No. Parts No. Description		Remarks			Fig. No.	Parts No.	Description		marks
1	A01-0603-08	Case	☆	1 B		53	R21-4302-08	Variable resistor 50kΩ(B) × 2	☆	6A
2	B42-1334-08	Adjustment sheet	☆	1 B				VR15, 16		
3	N09-0233-08	Binding head tap tight screw M4×8		1A,B	ĺ	54	X25-1310-00	MIC JACK PC board ass'y	☆	6B
4	A23-1207-08	Rear panel	☆	2B		55	X25-1260-01	REC/PLAY/OSC PC board	☆	6B
5	•	Power cord		1 B				ass'y		
6	•	Power cord bushing	Ì	28		56	K23-0612-08	Knob (OSC)	☆	6A
7	•	Power cord clamp holder A	☆	28		57	K23-0610-08	Knob (MEMORY REWIND)	☆	6A
8	•	Slide switch		2B		58	J21-2240-08	Back plate	☆	6A
9	•	Switch stopper holder		2B		59	_	_		
10	N08-0128-25	GND terminal		28		60	A21-0646-08	VU meter dress board	☆	6A
11	•	JACK PC board ass'y	☆	2B		61	X25-1360-00	MUTING (2) PC board ass'y	☆	2A
12	•	Panel ass'y (includes the parts of	☆	3A		62	_	_		
1		13,14,15,16,18 and 19)				63	_	_	1	_
13	B10-0501-08	Meter front glass	☆	2A		64	_	_		_
14	B07-051 1-08	Escutcheon for mechanism chassis	☆	2A		65	_	<u> </u>		_
4.5	202 0540 00	ass'y	١.			66	_	_		_
15	B07-0510-08	Escutcheon for tape counter	☆	3A		67	-	_		-
16 a 16b	B07-0508-08 B07-0509-08	Switch sleeve A Switch sleeve B	쇼	2A 3A		68	_	_		_
17	N29-0202-08	Nylon rivet \$\phi 3.5 \times 5.5	ដ	3A 2B		69 70	T42-0104-08	Mater		— 7В
18	B07-0205-04	Escutcheon (small)	☆	2B 3A		/0	142-0104-08	Motor		/ B
19	B07-0206-04	Escutcheon (big)	4	3A	1 1	71	G13-0415-08	Rubber for motor	☆	7B
20	K23-0614-08	Knob (lever switch, outside)	₩	3A		72	J31-0128-08	Faucet for motor	"	7B
			^	•		73	D21-0624-08	Stopping shaft	☆	7B
21	K23-0606-08	Knob (lever switch, inside)	☆	3A		74	N09-0208-18	Flywheel thrust adjusting screw	☆	7B
22	K23-0618-08	Knob (BIAS VR, outisde)	☆	3A		75	J19-1224-08	Flywheel holder ass'y	☆	7B
23	K23-0616-08	Knob (BIAS VR, inside)	☆	3A		76	G01-0638-08	Spring for returning	☆	7A
24	K23-0620-08	Knob (OUTPUT VR, outside)	☆	3A		77	D10-0521-08	Link lever for removing	☆	7A
25	K23-0608-08	Knob (OUTPUT VR, inside)	☆	3A	lΙ			pause lock		
26	K27-0051-04	Knob (lever switch)	☆	3A		78	D10-0477-08	Lever (1) ass'y for removing	☆	7A
27	A40-0518-08	Bottom plate	☆	3A				pause lock		
28	J02-0308-08	Leg		3B		79	D15-0503-08	Motor pulley ass'y	☆	7B
29	N09-0571-08	Binding head tap tight screw		3B	ŀ	80	N70-2003-16	Set screw	1	7B
30	•	Cassette lid	☆	3A		04	040 4000 00			7.4
31	_	_				81 82	S46-1302-08	Leaf switch (PAUSE)		7A 7A
32	F31-0403-08	Power transformer holder		4A	ll	82 83	T94-0055-08 D10-0478-08	Plunger Shut-off lever (2) ass'y	☆	7A
33	•	Power transformer	☆	4A		84	_		*	′^
34	F20-0404-08	Insulation plate	☆	4A		85	D10-0484-08	 Shut-off lever (1)	☆	7A
35	•	POWER SUPPLY/AUTO STOP	☆	4B		86	D01-0303-08	Flywheel ass'y	- L	7A
		PC board ass'y			i I	87	N19-0234-08	Washer $\phi 2.5 \times 0.25$	"	7A
36	F10-1009-08	Shielding plate for power	☆	4A		88	N19-0504-08	Polyethylene slider washer		7A
		transformer						$\phi 5 \times \phi 2.5 \times 0.25$		
37	J42-0308-08	Bushing		4B		89	S46-1304-08	Leaf switch for motor		7A
38	J21-2243-08	Top plate	☆	5B		90	_	_		
39	J19-0468-08	Lead holder		5B						ļ
40	J21-2241-08	Side plate	☆	5A,5B		91	G01-0294-08	Record prevention spring	垃	8A
						92	D10-0197-08	Brake operation lever		7A
41	F20-0403-08	Shielding plate for motor	☆	5B		93	D10-0199-08	Lock defeat plate		8A
42	J21-2242-08	Middle plate	ជ	5B		94	G01-0632-08	Brake operation lever spring	*	8B
43 44	 E20 0402 09	Insulating sheet for a suitable		50		95	D10-0469-18	Pause operation lever ass'y	☆	8B
44	F20-0402-08 B31-0501-05	Insulating sheet for power switch VU meter	쇼	5B 5A		96	G01-0633-08	Pause operation lever spring	☆	88
46	J21-2244-08	VU meter VU meter holder	압	5A 5A		97	D10-0195-18	FF interlock lever ass'y		8B 7B
	X25-1300-00	PEAK LED PC board ass'y	ਮ ☆	5A		98 99	G01-0297-08 D16-0206-08	FF interlock lever spring Flat belt	☆	7B
48	X25-1270-00	TEST TONE PC board ass'y	삽	6B		100	D10-0208-08	FR lever block ass'y	₩	7B
49	•	Power switch	☆	5A		.00	2,0 0400-00	ictor block uss y	1	, 3
	E11-0304-08	Headphone jack	•	6A		101	D10-0193-08	FR lever ass'ý		7A
		· · · · ·				102	D14-020 4-08	Idler "A" ass'y (FW idler)	☆	88
51	\$40-2304-08	Pushbutton switch for memory	ជ	6A		103	D14-0055-08	Idler "A1" ass'y		88
		rewind operation				104	D14-0203-08	ldler "A2" ass'y		88
52	X25-1290-00	LED PC board ass'y	☆ .	6A		105	N19-0529-08	Washer $\phi 2.5 \times 0.1$	1	88

